

# TABLE OF CONTENTS

**Electro-  
Motive  
Division  
(EMD)**

## GENERAL INFORMATION

Basic Locomotive Overview and Operation.....	1
---	---

## LOCOMOTIVE SYSTEMS

Fuel Oil System.....	14
Lubricating Oil System.....	18
Cooling Water System.....	24
Equipment Air System.....	32
Electrical System.....	36

## LOCOMOTIVE COMPONENTS

Governor and Load Regulator.....	44
Turbocharger.....	47
Dynamic Brake.....	49
Air Systems (Compressed Air).....	59
Load Meter.....	62
Emergency Fuel Cutoff Switches.....	63
Control Cabinet Panels.....	65
Protective Devices.....	78
Locomotive Control Stand.....	87

## LOCOMOTIVE TROUBLE SHOOTING

EMD Locomotive Troubleshooting.....	100
-------------------------------------	-----

## INTERGRATED CAB ELECTRONICS (ICE)

Introduction to ICE.....	113
--------------------------	-----

---

**General  
Electric  
(GE)**

**GENERAL INFORMATION**

Basic Locomotive Overview and Operation.....	135
Locomotive Starting Procedure.....	137

**LOCOMOTIVE ELECTRICAL AND  
MECHANICAL SYSTEMS**

Locomotive Systems.....	139
-------------------------	-----

**CONTROL AND PROTECTIVE DEVICES**

GE Dash 7 Locomotive.....	150
Microprocessor Controlled Locomotives.....	160
Display Screen Messages.....	162

**LOCOMOTIVE TROUBLE SHOOTING**

GE Locomotive Troubleshooting.....	172
------------------------------------	-----

**MECHANICAL GLOSSARY**

Glossary.....	180
---------------	-----

---